

LWA443 LWA444

USER MANUAL


LED WALL LAMP




1




3




5




6




2



4




7




Accessories	Accessories	Accessories
2mm Allen Key	expansion plug 2pcs screw 2pcs	connector 3pcs

1.SWITCH OFF MAIN
2.MAKE HOLE PATTERN
3.INSTALL THE BASE PLATE
4.CONNECT LAMP TO THE MAIN
5.DRIVE IN THE SCREWS UNTILL TIGHT
6.SWITCH ON THE MAIN AND LIGHT ON



LWA443
L127xW102xH64(mm)
LED-6W



LWA444
L127xW102xH128(mm)
LED-12W

Lamp：CREE XML LED
Color：2000K
Color rendering：Ra80
Input：100V-240V AC
Current：Constant 2000mA
Frequency：50/60Hz
Watt：6W/12W
Life span：20,000hrs
Operating temp：-20℃-+40℃
Indoor use only
IP20
Dimmable：NO

Cautions: a.Installed by qualified electrician
b.Use only power-supply supplied
by manufacturer for products guarantee